We are IntechOpen, the world's leading publisher of Open Access books Built by scientists, for scientists

6,300

Open access books available

172,000

International authors and editors

190M

Downloads

Our authors are among the

154

Countries delivered to

TOP 1%

most cited scientists

12.2%

Contributors from top 500 universities

WEB OF SCIENCE™

Selection of our books indexed in the Book Citation Index
in Web of Science™ Core Collection (BKCI)

Interested in publishing with us?
Contact book.department@intechopen.com

Numbers displayed above are based on latest data collected.
For more information visit www.intechopen.com

Limit of Detection and Limit of Quantification Determination in Gas Chromatography

Ernesto Bernal

Additional information is available at the end of the chapter

<http://dx.doi.org/10.5772/57341>

1. Introduction

Any year, millions of analyses of any kind are performed around the world, and millions of decisions are made, based on these analyses; have the medicaments, the amount of drug reported in their container?, Can we safely consume this water or these foods?, are these alloys suitable for use in the aircraft construction?, was the driver drunk, when he crashed?, is this sportsman using drugs to enhance his performance?, and if he was punished, there is no doubt, he was using those substances or we are unfair with him; all these questions are answered with the help of a chemical analysis and all have consequences in real life (compensation claims, disease, fines, even prison). Virtually every aspect of society is supported in some way by analytical measurement, consequently, there is a need these analyses would be reliable.

Until the 1970's, the underlying assumption was that the reports submitted by laboratories accurately described study conduct and precisely reported the study data. Suspicion about this assumption was raised during the review of some studies. Data inconsistencies and evidence of unacceptable laboratory practices came to light [1]. If the result of a test cannot be trusted then it has little value and the test might as well have not been carried out. When a client commissions analytical work from a laboratory, it is assumed that the laboratory has a degree of expertise that the client does not have. The client expects to be able to trust the results reported. Thus, the laboratory and its staff have a clear responsibility to justify the clients trust by providing the right answer to the analytical part of the problem, in other words, results that have demonstrable "fitness for purpose" [2]. Implicit in this is that the tests carried out are appropriate for the analytical part of the problem that the client wishes solved, and that the final report presents the analytical data in such a way that the client can readily understand it and draw appropriate conclusions. Method validation enables chemists to demonstrate that a method is "fit for purpose" [1]. For an analytical result to be fit for its intended purpose it must

be sufficiently reliable that any decision based on it can be taken with confidence. Thus the method performance must be validated and the uncertainty on the result, at a given level of confidence, estimated. Uncertainty should be evaluated and quoted in a way that is widely recognized, internally consistent and easy to interpret. Most of the information required to evaluate uncertainty can be obtained during validation of the method [1].

Since then, several agencies like United States Food and Drug Administration (FDA) [3-5], the International Conference for Harmonization (ICH) [6], the United States Pharmacopeia (USP) [7], the International Standards Organization (ISO/IEC) [8], etc. created working groups to ensure the validity and reliability of the studies. They would eventually publish standards for measurement the performance of laboratories and enforcement policy. Good laboratory practice (GLP) regulations were finally proposed in 1976, being method validation an important part of GLP.

1.1. Method validation

ISO [9] defines validation as the confirmation, via the provision of objective evidence, that the requirements for specifically intended use or application have been met, so method validation is the process of defining an analytical requirement, and confirming that the method under consideration has performance capabilities consistent with what the application requires [2].

Therefore, method validation should be an essential component of the measurements that a laboratory makes to allow it to produce reliable analytical data, in consequence, method validation should be an important part in the practice of all the chemists around the world. Nevertheless, the knowledge of exactly what needs to be done to validate a method seems to be poor amongst analytical chemists. The origin of the problem is the fact that many of the technical terms used in processes for evaluating methods vary in different sectors of analytical measurement, both in terms of their meaning and also the way they are determined [2].

In order to resolve the previous problem, several protocols and guidelines [2, 7, 10-19] on method validation have been prepared. Method validation consists of a series of tests that both proof any assumptions on which the analytical method is based and established and document the performance characteristics of a method, demonstrating whether the method fits for a particular analytical purpose [15]. Typical performance characteristics of analytical methods are applicability, selectivity or specificity, calibration, accuracy and recovery, precision, range, limit of quantification, limit of detection, sensitivity and ruggedness or robustness [2, 7, 10-19], Unfortunately, some of the definitions vary between the different organizations producing confusion among analysts. Some parameters are summarized in Table 1.

It's not the purpose of this work to define the previous parameters and the procedure to determine them or the strategies to perform a validation, all of them concerned with these issues are invited to consult the following references [2, 7, 10-19].

Parameter	Comment
Specificity	USP, ICH
Selectivity	ISO 17025
Precision	USP, ICH
• Repeatability	ICH, ISO 17025
• Intermediate precision	ICH
• Reproducibility	ICH
Accuracy	USP, ICH, ISO 17025
Linearity	USP, ICH, ISO 17025
Range	USP, ICH
Limit of detection	USP, ICH, ISO 17025
Limit of quantification	USP, ICH, ISO 17025
Robustness	USP; ISO 17025
Ruggedness	USP

Table 1. Parameters for method validation

1.2. Limit of detection

From the previous section, it is clear that despite the efforts to standardize concepts, there is still confusion about some terms in method validation, like selectivity and specificity, ruggedness and reproducibility, accuracy and trueness. Nevertheless, the most troublesome concept of all, in method validation is the limit of detection (LOD). LOD remains an ambiguous quantity on analytic chemistry in general and gas chromatography in particular; LOD's differing by orders of magnitude are frequently found for very similar chemical measurement process (CMP). Such discrepancies raise questions about the validity of the concept of the LOD.

The limit of detection is the smallest amount or concentration of analyte in the test sample that can be reliably distinguished from zero [20]. Despite the simplicity of the concept, the whole subject of LOD is with problems, translating these into the observed discrepancies in the calculation of the LOD. Some of the problems are [15]:

- There are several conceptual approaches to the subject, each providing a somewhat different definition of the limit, and consequently, the methodology used to calculate the LOD derived from these definitions, differ between them.
- LOD is confused with other concepts like sensitivity.
- Estimates of LOD are subject to quite large random variation.
- Statistical determinations of LOD assume normality, which is at least questionable at low concentrations.
- The LOD, which characterizes the whole chemical measurement process (CMP), is mistaken with concepts that characterize only one aspect of the CMP, the detection.

These problems are more prominent in the field of chromatography, where, besides the previous issues, no standard model for the LOD has ever proposed by any recognized organization. Actually, the International Union of Pure and Applied Chemistry (IUPAC) model for LOD determination was chosen for spectrochemical analysis specifically. Thus, chromatographic conditions are usually not taken in consideration to determine the LOD [15, 21].

The main purpose of this paper is to bring some light to these problems. In order to achieve this goal, the different problems behind LOD and limit of quantification (LOQ) are going to be discussed. The different definitions and conceptual approaches to LOD and LOQ, given by different associations [2,7,20, 22], the different models to calculate LOD and LOQ, and the effect of matrix and particularities related to chromatographic techniques on LOD and LOQ calculations are going to be critically reviewed [23-25], aiming at unifying criteria and estimating LOD and LOQ in a more reliable figure of merit in chromatography.

2. Limit of detection and limit of quantification

2.1. Definitions

Since the seminal work of Currie [26], emphasis has been placed on the negative effect it has had, the large number of terms that have been used through the years regarding the detection capabilities of a method (table 2). A wide range of terminologies and multiple mathematical expressions have been used to define the limit of detection concept. These different terms resulted in different ways of calculating the LOD, leading to numerical values that can span over three orders of magnitude, applied to the same measurement process. Some mathematical definitions involved the standard deviation of the blank, some the standard deviation of the net signal, some authors used two sided confidence intervals, while others used one sided intervals, and some authors even used non statistical definitions; what was missing from these authors was a theoretical basis for the concept that led to an operational definition of the term.

To overcome the previous problem, the ISO and the IUPAC developed documents bringing their nomenclature into essential agreement [15, 20, 22]. As the measure of the detection capability of a CMP, the IUPAC recommends the term Minimum Detectable Value (L_D) of the appropriate chemical variable or Detection limit and defines it as the smallest amount or concentration of analyte in the test sample that can be reliably distinguished from zero. And as the measure of the quantification capability of the CMP, the IUPAC recommends the term Minimum quantifiable limit (L_Q) or Quantification limit, which is the concentration or amount below which the analytical method cannot operate with an acceptable precision. ISO definition puts emphasis in the statistics; ISO [2, 22] defines the minimum detectable net concentration as the true net concentration or amount of the analyte in the material to be analyzed, which will lead with probability $(1-\beta)$ to the conclusion that the concentration of the analyte in the analyzed material is larger than that of the blank matrix.

In addition, several organizations have introduced terms with similar meaning to LOD. The US Environmental Protection agency (EPA) uses the term method detection limit (MDL) as

the minimum concentration of an analyte that can be identified, measured and reported with 99% confidence that the analyte concentration is greater than zero.

On the other hand, the ICH defines LOD as the lowest amount of analyte in a sample which can be detected but not necessarily quantitated as an exact value and LOQ of an individual analytical procedure as the lowest amount of analyte in a sample which can be quantitatively determined with suitable precision and accuracy [19, 27].

The American Chemical Society (ACS) committee on environmental improvement states LOD as the lowest concentration of an analyte that the analytical process can reliably detect [27].

The conference for drug evaluation and research (CDER) in its document entitled 'Validation of chromatographic method' defines LOD as the lowest concentration of analyte in a sample that can be detected but not necessarily quantitated under the stated experimental conditions [19, 27].

The national association of testing authorities (NATA) defines LOD as the smallest amount or concentration that can be readily distinguished from zero and be positively identified according to predetermined criteria and/or level of confidence, while the lowest concentration of an analyte that can be determined with acceptable precision (repeatability) and accuracy under the stated conditions of the test is the limit of quantification [2, 27].

On the other hand, the AOAC defines limit of detection as the lowest content that can be measured with reasonable statistical certainty and the limit of quantification as the content equal to or greater than the lowest concentration point on the calibration curve [2].

Finally, the USP [7] defines LOD as: the lowest amount of analyte that can be detected but not necessarily quantitated under the stated experimental conditions. Table 2 summarizes these terms, symbols and statistical items reported in the literature [28].

All definitions include terms as reliability, probability, confidence, etc. That implies the use of statistics to calculate them. Some definitions even put inside its text explicitly the degree of reliability and consequently, define it. The others leave the decision to the operator. Some definitions make it clear that they are referring to a CMP and not only to the detection phase of the analysis. Therefore, these terms should not be confused with terms referred only to detection like the Instrumental Detection Limits (IDL) used by EPA. The limit of detection is a parameter set before the measure, and, in other words, is defined a priori; therefore, is not related to the decision whether a measurement detects anything or not. Finally, these terms should not be confused with sensitivity defined as the slope of the calibration curve by IUPAC.

As an example of the wide range of terms used to define detection capabilities of a method used nowadays, it is shown a study performed in 2002 [29], by the American Petroleum Institute (API), to intend to review policies related to analytical detection and quantification limits of ten states of the USA, with particular focus on water quality and wastewater issues in permitting and compliance. Thus, these regulations should follow the EPA recommendations. It was found that every state incorporates detection or quantification terms in its

regulations to some extent. Terms referenced are usually defined in the regulations, but not always. The most frequently used terms are detection limit/level, method detection limit (MDL), limit of detection (LOD), and practical quantitation level (PQL). Minimum Level (ML) is the term used by EPA instead of LOQ; it is defined as the concentration at which the entire analytical system must give a recognizable signal and acceptable calibration point. The ML is the concentration in a sample that is equivalent to the concentration of the lowest calibration standard analyzed by a specific analytical procedure, assuming that all of the method-specified sample weights, volumes, and processing steps have been followed. EPA uses other terms like Interim minimum level (IML) which is a term created by the EPA to describe MLs that are based on 3.18 times the MDL, to distinguish them from MLs that have been promulgated. The EPA defines the PQL as: The lowest level that can be reliably achieved within specified limits of precision and accuracy during routine laboratory operating conditions. Another term used by EPA is the alternative minimum level (AML) which can account for interlaboratory variability and sample matrix effects and finally the Interlaboratory Quantification estimate (IQE) a term developed by the American Society for Testing and Materials (ASTM), which is similar to the AML. Table 3 lists detection and quantification terms used by the ten states.

Terms	Signal Domain	Concentration Domain	Reference
Limit of detection	LOD	LOD	IUPAC 1976
		LOD	ACS, 1980
Critical Level	L_c	X_c	Oppenheimer, et al, 1983
	y_c	X_c	Hubaux & Vos, 1970
Critical value	L_c	X_c	Currie, 1995
Method detection limit		MDL	EPA
Limit of guarantee of purity	x_G	c_G	Kaiser, 1966
Limit of identification	x_i	c_i	Long & Winefordner, 1983
Detection level	L_D	X_D	Oppenheimer, et al, 1983
Detection limit	y_D	x_D	Hubaux & Vos, 1970
Minimum detectable value	L_D	X_D	Currie, 1995
Limit of quantification		LOQ	ACS, 1980
	LOQ		Long & Winefordner, 1983
Determination Limit	L_Q	x_Q	Oppenheimer, et al, 1983
Minimum Quantifiable level	L_Q	x_Q	Currie, 1995
Minimum Level		ML	EPA
		PQL, IML	EPA

Table 2. Terms and symbols reported in the literature related to method detection capabilities

Therefore, despite the efforts of various agencies to standardize the terms concerning the detection capability of a measurement process, there are still differences between the various regulations.

2.2. Theory

2.2.1. Hypothesis testing approach

In 1968, Currie published the hypothesis testing approach to detection decisions and limits in chemistry [26]. This approach has gradually been accepted as the detection limit theory.

Currie's achievement was in recognizing that there were two different questions under consideration when measurements were performed on a specimen under test, and these two questions have different answers. The first question, which was "does the measurement result indicate detection or not?", is answered by performing measurements on the specimen under test then computing an appropriate measure for comparison with a critical decision level. The second question is "what is the lowest analyte content that will reliably indicate detection?" and the answer is defined as the detection limit.

State programs	DL	IDL	IML	LOD	LOQ	MDL	ML	QL	PQL	Other [§]
Alabama										
Groundwater soil/ hazardous waste	x			x					x	
Water quality	x		x			x	x			
California										
Drinking water	x						x			DLR
Groundwater soil/ hazardous waste	x	x		x		x			x	
Health/Safety				x						
Water quality					x	x	x		x	
Illinois										
Drinking water	x					x			x	MQL, ADL
Groundwater soil/ hazardous waste	x			x		x			x	EDL, EQL, MQL
Laboratories						x				
Pesticides	x					x				MQL
Water quality	x			x	x	x	x	x		

State programs	DL	IDL	IML	LOD	LOQ	MDL	ML	QL	PQL	Other [§]
Louisiana										
Air	x			x	x					
Groundwater soil/ hazardous waste	x			x				x	x	
Water quality	x									LOM, MQL**
New Jersey										
Drinking water						x				
Groundwater soil/ hazardous waste	x	x			x	x		x	x	CRDL
Laboratories	x	x				x				
Water quality	x					x			x	NJQL LOD*
Ohio										
Air					x					
Drinking water	x					x				
Groundwater solid/ hazardous waste	x			x					x	ADL
State programs	DL	IDL	IML	LOD	LOQ	MDL	ML	QL	PQL	Other
Laboratories						x				
Underground storage tanks						x		x		
Water quality						x	x	x	x	ADL
Oklahoma										
Air	x									ADL, MLD, MQL*
Drinking water										MDL*
Groundwater solid/ hazardous waste	x			x					x	
Water quality									x	MQL*
Pennsylvania										
Air										
Drinking water						x			x	

State programs	DL	IDL	IML	LOD	LOQ	MDL	ML	QL	PQL	Other ^s
Groundwater solid/ hazardous waste						X		X	X	EQL
Water quality	X			X		X			X	
Texas										
Air	X									
Drinking water	X					X			x	
Groundwater solid/ hazardous waste	X			X		X			x	MQL, SQL
Water quality						X				MAL
Washington										
Air									X	
Drinking water	X									
Groundwater solid/ hazardous waste	X			X	X	X			X	
Water quality	X					X			X	
§ Definitions on section 4										

Table 3. Summary of detection and quantification terms used by the states

According to Currie, the IUPAC and ISO [20, 30-31], detection limits (minimum detectable amounts) are based on the theory of hypothesis testing and the probabilities of false positives α , and false negatives β . On the other hand, quantification limits are defined in terms of a specified value for the relative standard deviation. It is important to emphasize that both types of limits are CMP performance characteristics, associated with underlying true values of the quantity of interest; they are not associated with any particular outcome or result. The detection decision, on the other hand, is result-specific; it is made by comparing the experimental result with the critical value which is the minimum significantly estimated value of the quantity of interest. In other words it is used to make a posteriori estimate of the detection capabilities of the measurement process, while the limit of detection is used to make a priori estimate.

In order to explain the detection limit theory, let's assume we have an analytical method with known precision along all its concentration levels and that its results follow a normal distribution, if we test a lot of blanks with the method above, certainly a distribution as in Figure 1 can be obtained.

The blank values will distribute around zero with a standard deviation σ_0 . In others words if we measure a blank, we can obtain a result different from zero due to the experimental errors of the measure process. Thus we need to establish a point to differentiate blanks measures from non blank measures. That point is the critical value L_C that point allows us to determine

Figure 1. Value distribution around zero and the critical level.

if a signal corresponds to a blank or if the signal is from an analyte, i.e. to make a posterior decision. Nevertheless, in the critical level there is the probability (blue shadow) that a blank can give a signal above the L_C . Therefore we can erroneously conclude that there is analyte, when is not. That probability α , is named type I error or a false positive. The value of α is chosen by the analyst in function of the risk that one wants to take of being wrong. The hypothesis testing theory uses the following definition.

$$\Pr (L > L_C | L=0) \leq \alpha \quad (1)$$

Where, L is used, as the generic symbol for the quantity of interest. This is replaced by S , when treating net analyte signal and x , when treating analyte concentrations or amount; mathematically, the critical level is given as:

$$L_C = K_\alpha \sigma_0 \quad (2)$$

Where K_α and α , are linked with the one sided tails of the distribution of the blank corresponding to probability levels, $1-\alpha$.

Nevertheless, the critical level L_C cannot be used as the limit of detection, because if we measure a series of samples with an amount of analyte equal to the L_C , the results will follow like the blanks a normal distribution around the L_C value (Figure 2). Half of the results would be above the L_C and we conclude that the signal is from an analyte, and half would be below the L_C and consequently, we would think the sample is a blank. Therefore, if we set the L_C as the limit of detection, we would report erroneously half of the results; then, there is the possibility to report

that the analyte is not present in the sample, when it actually is. The probability β , is named type II error or a false negative.

Therefore, if a laboratory cannot accept a 50% of error around the limit of detection, the only alternative to reduce the probability of false negative is to set the limit of detection to a bigger concentration (Figure 3).

Figure 2. Critical level and limit of detection with probability α . The risk of a false negative is 50%.

Once L_C has been defined, a priori limit of detection L_D , may be established by specifying L_C , the acceptable level β , for the type II error and the standard deviation, σ_D , which characterizes the probability distribution of the signal when its true value is equal to L_D [26]. By the hypothesis testing theory, we obtain the following relation:

$$\Pr(L \leq L_C | L = L_D) = \beta \quad (3)$$

Mathematically, the limit of detection is given as:

$$L_D = K_\alpha \sigma_0 + K_\beta \sigma_D \quad (4)$$

If equation 2 is substituted in equation 4, we obtain:

$$L_D = L_C + K_\beta \sigma_D \quad (5)$$

Where K_β and β , are linked with the one sided tails of the distribution of the limit of detection corresponding to probability levels, $1-\beta$. Finally, the defining relation for the limit of quantification (L_Q) is:

$$L_Q = K_Q \sigma_Q$$

(6)

Where $K_Q = 1/\text{RSD}_Q$, and σ_Q equals the standard deviation of L when $L = L_Q$.

Figure 3. Critical level and limit of detection with $\alpha = \beta$.

Summarizing, the levels L_C , L_D and L_Q , are determined by the error structure of the measurement process, the risks α and β and the maximum acceptable relative standard deviation for quantitative analysis. L_C is used to test an experimental result, whereas L_D and L_Q refer to the capabilities of the measurement process itself. The relations among the three levels and their significance in analysis are shown in Figure 4.

Figure 4. The three principal analytical regions [26].

α , β and K_Q can be chosen by the analyst according to the detection and quantification needs; of particular interest is when $\alpha=\beta$, and $\sigma=\text{constant}$, in that circumstances $K_\alpha = K_\beta = K$, and $\sigma_D = \sigma_0$

$$L_C = K\sigma_0 \quad (7)$$

$$L_D = L_C + K\sigma_D = K(\sigma_0 + \sigma_D) \quad (8)$$

And because $\sigma=\text{constant}$, $\sigma_0=\sigma_D=\sigma$, relation 7, can be written as:

$$L_D = 2K\sigma = 2L_C \quad (9)$$

In this particular case the limit of detection is twice the critical level. The values of α and β recommended by IUPAC and ISO regulations are 0.05 each, which gives a value of $K=1.645$, and since $\sigma=\text{constant}$, it can choose either the value of σ_0 or σ_D , because L_D is not known, in equation 9 the value of σ_0 is used. Under these circumstances (normal distribution, constant standard deviation and parameters $\alpha=\beta=0.05$) the following expressions are obtained [20, 26, 30-31].

$$L_C = K\sigma_0 = 1.645 \sigma_0 \quad (10)$$

If σ_0 is estimated by s_0 , based on v degrees of freedom, K can be replaced by Student's t , resulting in equation:

$$L_C = t_{1-\alpha, v} s_0 \quad (11)$$

For $\alpha=0.05$ and four degrees of freedom, equation 12 is obtained.

$$L_C = 2.132 \sigma_0 \quad (12)$$

Following the procedure developed in the previous paragraphs, equivalent equations are obtained for the limit of detection.

$$L_D = L_C + K\sigma_D = 3.29 \sigma_0 \quad (13)$$

If L_C employs an estimate s_0 , based on v degrees of freedom, then K can be replaced by $\delta_{\alpha, \beta, v}$, the non centrality parameter of the non central t distribution. If $\alpha=0.05$ and four degrees of freedom are used, equation 14 is obtained.

$$L_D = \delta_{\alpha, \beta, v} \sigma_0 = 2t_{1-\alpha, v} \sigma_0 = 4.26 \sigma_0 \quad (14)$$

The ability to quantify is expressed in terms of the signal or analyte that will produce estimates having a specified relative standard deviation (RSD), commonly 10%. That is

$$L_Q = K_Q \sigma_Q = 10 \sigma_0 \quad (15)$$

Where, L_Q is the limit of quantification, σ_Q , the standard deviation at the limit of quantification and K_Q is the multiplier whose reciprocal equals the selected RSD; the IUPAC default value is 10. It's possible to transform all those expressions from the signal domain to concentration domain, and vice versa through the slope of the calibration curve.

The above relations represent the simplest possible case, based on restrictive assumptions. Actually, some of them are questionable as the assumption of normality in the blank measures and that σ is constant along the region of the critical level and limit of detection. They must not be taken as the defining relations for detection and quantification capabilities; being the defining relations, equation one, three and six for the critical level, the limit of detection and the limit of quantification respectively. Finally, for chemical measurement at least, the Fundamental contributing factor to the detection and quantification performance characteristics is the variability of the blank.

Currie's hypothesis testing schema, in spite of being theoretically solid, is very broad in scope, being independent of noise, the methodology to perform the measurements, conditions, etc. In fact his schema does not even have a connection to the calibration curve methodology or even the substance that would be measured.

A particular problem for the calculation of the limit of detection within the field of gas chromatography is the calculation of the deviation of the blank. It has been suggested to use the measurement of 20 blanks and calculate its standard deviation. Other authors suggest measuring the noise at the baseline of one chromatogram in a region near the analyte peak [21]. Nevertheless, questions arise about the sets of the integration parameters, the region of the baseline which should be used to calculate the blank variability and the presence of interfering substances. This makes the determination of s_0 subjective and highly variable and has a major drawback in using the IUPAC definition in dynamic systems such as chromatography [23]. In order to introduce the calibration curve in the limit of calculation, other approaches have been developed to calculate the detection capabilities of a CMP.

2.2.2. Hubaux- Vos approach

In 1970, Hubaux and Vos suggested how Currie's schema could be implemented with calibration curve methodology based on CMP, with homoscedastic ($\sigma = \text{constant}$), Gaussian noise, ordinary least square processing of the calibration curve data and ordinary least square prediction intervals [32]. Since then, Hubaux and Vos' treatment has generally been assumed to be fundamentally correct.

Hubaux and Vos made a series of assumptions to develop their approach, It was assumed that the standards of the calibration curve are independent, that the deviation is constant through

the calibration curve, the contents of the standards are accurately known and above all, the signals of all the points in the calibration curve have a Gaussian distribution (Figure 5).

Then Hubaux and Vos drew two confident limits on either sides of the regression line with a priori level of confidence (Figure 5), $1-\alpha-\beta$. The regression line and its two confident limits can be used to predict with a $1-\alpha-\beta$ probability, likely values for signals. The confidence band can be used in reverse, for a measured signal y of a sample of unknown content, it is possible to predict the range of its content ($x_{\max}$ - $x_{\min}$) (Figure 5).

To our subject, a signal equal to y_c is of interest (Figure 5), where the lower limit of content is zero. Signals equal or lower than y_c have a probability bigger than α due to a blank, and hence cannot be distinguished from a blank signal. y_c is the lowest measurable signal and therefore corresponds to the critical level L_c of Currie. More exactly y_c is an estimate of L_c . Because this limit concerns signals, it is used to posteriori decisions.

If we trace a line from y_c to the lower confident limit and then to the x axis (Figure 5), the value x_D can be obtained, which is the lowest content it can be distinguished from zero. This value is inherent to the CMP and can be used as a priori limit, thus is equivalent to the limit of detection L_D of Currie. It is important to clarify that the regression line and its confident limits are estimates of the real values. Consequently, the values of y_c and x_D are estimates too [32].

Figure 5. The linear calibration line, with its upper and lower confidence limits. y_c is the decision limit and x_D the detection limit [33].

One serious problem with the Hubaux-Vos approach is the non-constant widths of the prediction interval which contradicts the assumption of homoscedasticity; another problem is, because y_c and x_D are estimates, this method requires the generation of multiple calibration curves to calculate the mean of y_c and x_D .

2.2.3. Propagation of errors approach

In the hypothesis testing approach, the value of the limit of detection L_D depends only on the variability of the blanks σ_0 . The propagation of errors approach considers the standard deviation of the concentration s_x . This value is calculated by including the standard deviations of the blank s_0 , slope s_m , and intercept s_i , in the equation [25]. The contribution of the variability of slope, blank and intercept to the variability of x is expressed by the formula:

$$s = \frac{\left[s_0^2 + s_i^2 + \left(\frac{1-y}{m} \right)^2 s_m^2 \right]^{1/2}}{m} \quad (16)$$

The standard deviation of the concentration is equal to s_D , and because it was assumed that, the standard deviation is constant along the region of interest $s_0=s_D=s$, it can substitute s_0 in any of Currie relations. If we substitute equation 16 in equation 13, and we assume the blank's signal is set to zero the following relation is obtained.

$$L_D = \frac{k \left\{ s_0^2 + s_i^2 + \left[\left(\frac{i}{m} \right)^2 s_m^2 \right] \right\}^{1/2}}{m} \quad (17)$$

Where K is a constant related to the degree of error, the analysts assume. The mathematical expressions for s_0 , s_i and s_m , can be found in [25] and publications specialized in statistics.

Experimentally, it has been found that the IUPAC approach, based exclusively on the blank variability, in most cases, gives lower values of L_D than the propagation of error approach, which, besides the errors of the blank, takes into account errors in analyte measurement (slope and intersect). Consequently, the propagation of errors approach gives More realistic values of L_D and consistent with the reliability of the blank measures and the signal measures of the standards. In the literature, the propagation of errors is preferred in many chemistry fields [25].

In order to calculate the limit of detection with the propagation of errors approach, it is necessary to make a minimum of five calibration curves to be able to measure s_i and s_m properly, All of these calibration curves would have to be prepared by fortifying control samples with the analyte of interest at concentrations around an estimated limit of detection. This would make the procedure cumbersome for dynamic systems such as chromatography [23].

2.2.4. Root mean square error approach

In this approach, the root mean square error (RMSE) is used instead of the standard deviation of the blank σ_0 in equations 7, 9 and 15, corresponding to L_C , L_D and L_Q , respectively. In order

to calculate the LOD, it is necessary to generate a calibration curve, from which the values of the slope (m) and intersect (i) are obtained. From these values and the equation of the calibration curve a predicted response is calculated (y_p), and then the error associated with each measurement:

$$[y_p - y] \quad (18)$$

Then the sum of the square of the errors is calculated for all the points of the calibration curve, and finally the RMSE.

$$RMSE = \left[\frac{\sum_{i=1}^n (Y_{ip} - \bar{Y})^2}{n - 2} \right]^{1/2} \quad (19)$$

Since the RMSE is calculated from a calibration curve, this approach uses both the variability of the blank and of the measurements. For dynamic systems, such as chromatography with autointegration systems, RMSE is easier to measure and more reliable than σ_0 [23].

2.2.5. The $t_{99sLLMV}$ approach

This method to calculate the MDL analyzed seven fortified samples with amounts of analyte close to an estimated limit of quantitation (ELOQ) or the lowest limit of method validation (LLMV) and its standard deviation $s_{ELOQ/LLMV}$ was calculated. This value in a way is a substitute of σ_D in Currie's definitions. Because this approach was developed by EPA, it is used to determine the MDL with the relation:

$$MDL = t_{99n-1} s_{ELOQ/LLMV} \quad (20)$$

Where, t_{99n-1} is the one sided Student's t for N-1 observations (six degrees of freedom in our case) at the 99% confidence level. In this case $t_{99n=1}$ equals to 3.143.

However, it is extremely important that the ELOQ be accurately determined, because the fortification concentration greatly influenced the final value of MDL and MQL determined by this approach. EPA recommends that if the calculated MQL is significantly different from the ELOQ, the procedure has to be repeated with the calculated MQL as the new ELOQ, and MDL and MQL should be recalculated. This should be done until the calculated values are in the range of the estimated values. This approach is considered a fairly accurate way to determining method detection limits [23]. This approach is similar in some aspects to the so-called empirical

method [24, 33], where increasingly lower concentrations of the analyte are analyzed until the measurement do not satisfy a predetermined criteria.

2.2.6. Baseline noise approach

The IUPAC and propagation of errors approaches were developed for spectroscopic analysis. Nearly all concepts used in this approach have an equivalent in chromatography, except the interpretation and measurement of S_0 . It has been proposed that the chromatographic baseline is analogous to a blank and S_0 must represent a measure of the baseline fluctuations [21, 23].

Therefore, in order to calculate the LOD and LOQ it is necessary to measure the peak-to-peak noise (N_{p-p}) of the baseline around the analyte retention time. N_{p-p} can be related to the standard deviation of the blank through the relation [21]:

$$s_0 = \frac{N_{p-p}}{5} \quad (21)$$

In spite of being the simplest path to determine the detection capabilities of a chromatographic method, this approach is not recommended because it is very dependent on analyst interpretation since, there is no agreement on where to measure the noise and the extension of baseline that has to be measured. Therefore, the obtained results show great variability between laboratories and even between analysts and consequently, they are hard to compare.

3. Conclusions

The limit of detection is an important figure of merit in analytical chemistry. It is of the utmost importance, in the development of methods to test the detection capabilities of a method and although it is not necessary to calculate it in the process of validation of all methods. It finds applications in areas such as environmental analysis, food analysis and areas under great scrutiny such as forensic science, etc.

Although the detection limit concept is deceptively simple, little is understood by the chemistry community. This caused the proliferation of terms relating to the detection capabilities of a method with different approaches for its determination and impeded efforts to harmonize the methodology.

Although various authors and agencies [20-28, 30-32] have published their own definitions of the detection limit of analytical method, nowadays, the limits of detection and quantification are commonly accepted as that in the hypothesis testing detection limit theory [20, 26, 28, 30-32].

This theory states:

- Limits of detection are actual true values, which can be determined.

- Both Limits are chemical measurement process (CMP) performance characteristics, and therefore, involve all the phases of the analysis. Consequently should not be confused with terms referred exclusively to the detection capabilities of the instrument like IDL.
- Detection limits are not associated with any particular outcome, they are a priori limit
- The existence of both type I errors (false positives) and type II errors (false negatives).
- Detection decision is based on the other hand on a posteriori limit, the critical value.
- Detection limits should not be confused with sensibility, which is the slope of the calibration curve.

In developing the limit of detection theory, Currie made a series of assumptions. First, the measurement distribution of the blanks follow a normal distribution, which is questionable at low concentrations, and secondly, in order to obtain simplified relations, the standard deviation is constant over the range of concentrations studied (homoscedasticity). In this specific circumstances the detection capabilities of a method depends exclusively on blank variability [20, 26, 30-31].

Even Hubaux-Vos prediction bands with their non-uniform width proves that the assumption of homoscedasticity is false. Currie and other authors [26, 28, 30-31] have addressed this problem, but stated that if the standard deviation increases too sharply, limits of detection may not be attainable for the CMP in question.

Although in Currie's simplified relations, limits of detection exclusively depend on blank variability; other sources of error can be introduced in making the transition from the signal domain to the concentration domain through the uncertainty of the slope and intercept of the calibration curve. To take this into account several approaches have been developed like the propagation error approach, Hubaux –Vos, RMSE, etc [23-26, 32]. Actually, the IUPAC approach which does not account measurement variability, usually gives artificially low values of limit of detection, while methods which account slope and intercept uncertainties, like the propagation error method and Hubaux-Vos method give more realistic estimates, consistent with the reliability of the blank measure and the signal measure of the standards.

In other words, Currie's simplified equations can only be valid, when all their assumptions are met (normal distribution, homoscedasticity, main source of error is the blank). To achieve this, a good knowledge of the blanks is needed to generate confidence in the nature of the blank distribution and some precision in the blank RSD is necessary; therefore an adequate number of full scale true blanks must be assayed through all the CMP.

Most of the assumptions of the IUPAC method are fulfilled in spectrophotometric analysis, for which it was developed, and where it has been used successfully. However, in the case of gas chromatography, where dynamic measures are carried out, and no practical rules are defined to measure the blank standard deviation; the error associated to the intersect of the calibration curve is not always negligible, and the presence of interferences is important. It is better to use a method that takes into account these sources of error. Therefore, for chromatographic techniques it is not recommended the IUPAC approach for the calculation of the

detection capabilities of the method. Instead, the propagation of error, Hubaix- Vos, RMSE and $t_{99sLLMV}$ approaches, which take into account the errors of the measurements of the analyte through a calibration curve, are recommended. A brief comparison of the different approaches for the determination of the detection capabilities of a CMP can be found in Table 4.

Method	Easy to apply	Variability of calibration curve	Considers method efficiency and matrix effect	Variability between laboratories and analysts
KS_0	No	No	Yes	Moderate
N_{p-p}	Yes	No	Yes	High
Propagation of errors	No	Yes	No	Low
Hubaux - Vos	No	Yes	No	Low
RMSE	Yes	Yes	No	Low
$t_{99sLLMV}$	Yes	Yes	Yes	Low

Table 4. Comparison of approaches for calculating detection and quantification limits for analytical method

Since several methods can be used, and could be a difference in the limit of detection calculated by them, it is important that when reporting values of limits of detection, the method used to define these values should be clearly identified in order to have meaningful comparisons.

In order to properly determine the limit of detection and limit of quantification of a method, it is necessary to know the theory behind them, to recognize the scope and limitations of any approach, and be able to choose the method that better suits our CMP. The intention of this chapter is to review the fundamentals of detection limits determination for the purpose of achieving a better understanding of this key element in trace analysis, in particular and analytical chemistry in general; and to achieve a more scientific and less arbitrary use of this figure of merit with a view to their harmonization and avoid the confusion about them, which still prevails in the chemical community.

Nomenclature

α	Type I error, false positive
ACS	American Chemical Society
ADL	Analytical Detection Level
AML	Alternative Minimum Level
API	American Petroleum Institute
ASTM	American Society for Testing and Materials

β	Type II error, false negative
CDER	Conference for Drug Evaluation and Research
CMP	Chemical Measurement Process
CRQL	Contract Required Quantitation Limit
DL	Detection limit/level
DLR	Detection Limit for Purpose of Reporting
$\delta_{\alpha,\beta,v}$	the non centrality parameter of the non central t distribution
EDL	Estimated Detection Limit
ELOQ	Estimated limit of quantification
EPA	(United States) Environmental Protection Agency
EQL	Estimated Quantitation Limit
FDA	United States Food and Drug Administration
GLP	Good Laboratory Practice
i	Intersect of the calibration curve
ICH	International Conference for Harmonization
IDL	Instrumental Detection Limit
IML	Interim Minimum level
IQE	Interlaboratory Quantication Estimate
ISO/IEC	International Standards Organization
IUPAC	International Union of Pure and Applied Chemistry
K_{α}	the one sided tails of the distribution of the blank corresponding to probability levels, $1 - \alpha$
K_{β}	the one sided tails of the distribution of L , when $L=L_D$ corresponding to probability levels, $1 - \beta$
L	Quantity of interest
L_c	Critical value
L_D	Minimum detectable value
L_Q	Minimum Quantification level/value
LLMV	Lower limit of method validation
LOD	Limit of Detection
LOD*	Limit of detectability
LOM	Limit of Measurement
LOQ	Limit of Quantification
m	Sensitivity, slope of calibration curve
MAL	Minimum Analytical Level

MDL	Method Detection Limit
MDL*	Minimum Detection Limit
ML	Minimum Limit
MLD	Minimum Level of Detectability
MQL	Method quantitative limit
MQL*	Minimum quantification level
MQL**	Minimum analytical quantification level
N_{p-p}	Peak to peak noise
NJQL	New Jersey Quantitation Level
PQL	Practical Quantification Level
Pr	Probability
QL	Quantification Level
RMSE	Root mean square error
RSD_Q	Relative standard deviation when $L=L_Q$
S	Analyte signal
σ_0	Standard deviation of the blank
σ_D	Standard deviation when $L=L_D$
σ_Q	Standard deviation when $L=L_Q$
$s_{ELOQ/LLMV}$	Standard deviation when $L=ELOQ$ or $L=LLMV$
SQL	Sample Quantitation Limit
$t_{1-\alpha, v}$	Student's t, with a probability α and v degrees of freedom
t_{99n-1}	One sided Student's t, for N-1 observations at the 99% confidence level
USP	United States Pharmacopeia
x	Amount or concentration
x_D	The lowest content it can be distinguished from zero
y_c	The lowest measurable signal
y_p	Predicted response

Acknowledgements

I would like to acknowledge to the Chemical Engineer Sarai Cortes for the exchange of ideas and knowledge on this subject and the joint work.

Author details

Ernesto Bernal^{1,2*}

Address all correspondence to: ernestob066@gmail.com

1 Faculty of Criminology, University of Ixtlahuaca CUI, Mexico, Ixtlahuaca, Estado de Mexico, Mexico

2 Chemistry Department, Forensic Science Institute of Mexico City, México

References

- [1] Hirsch AF. Good laboratory practice regulations. New York: Marcel Dekker; 1989.
- [2] EURACHEM Guide: The fitness for purpose of analytical methods. A Laboratory Guide to method validation and related topics. Teddington: LGC; 1998.
- [3] Title 21 of the US Code of federal regulations: 21 CFR 211, Current good manufacturing practice for finished pharmaceuticals. Washington: U.S. Government Printing Office; 2012.
- [4] Title 21 of the US Code of federal regulations: 21 CFR 58, Good laboratory practice for nonclinical laboratory studies. Washington: U.S. Government Printing Office; 2012.
- [5] Title 21 of the US Code of federal regulations: 21 CFR 320, Bioavailability and bioequivalence requirements. Washington: U.S. Government Printing Office; 2012.
- [6] ICH Q7A: Good Manufacturing practice guide for active pharmaceutical ingredients. Rockville: ICH; 2001.
- [7] USP 32- NF27. General chapter 1225, Validation of compendial methods. Rockville: USP; 2009.
- [8] ISO/IEC 17025, General requirements for the competence of testing and calibration laboratories. 2nd Edition, Switzerland: ISO/IEC; 2005.
- [9] ISO 9000: Quality management systems – Fundamentals and vocabulary. Geneva: ISO; 2005
- [10] ISO, Guide to the expression of uncertainty in measurement. Geneva: ISO; 1995
- [11] Youden WJ, Steiner EH. Statistical manual of the AOAC. Gaithersburg: AOAC International; 1975
- [12] Validation of analytical procedures: text and methodology Q2(R1). Rockville: ICH; 2005

- [13] Validation of analytical methods for food control. Report of a joint FAO/IAEA expert consultation. Rome: FAO; 1998
- [14] Thompson M, Ellison RL, Wood R. Harmonized guidelines for single laboratory validation of methods of analysis. *Pure Appl. Chem.* 2002; 74(5), 835–855.
- [15] U.S. FDA – Guidance for Industry (draft): Analytical Procedures and Methods validation: chemistry, Manufacturing, and Controls and Documentation, Rockville: FDA; 2000
- [16] Lopez Garcia P, Buffoni E, Pereira Gomez F, Vilchez Quero JL. Analytical method validation. Wide spectra of quality control. In Akyar I. (ed.), *In Tech*. Rijeka: In Tech; 2011
- [17] Huber L. Validation of analytical method. A primer. Germany: Agilent; 2010
- [18] Reviewer Guidance, Validation of Chromatographic Methods. Rockville: Center for Drug Evaluation and Research; 1994
- [19] Validation and Peer Review of US EPA Chemical Methods of Analysis, EPA; 2005
- [20] Currie LA. Nomenclature and evaluation of analytical methods, including quantification and detection capabilities. *Pure Appl. Chem.* 1995; 67(10) 1699-1723.
- [21] Foley JP, Dorsey JG. Clarification of the limit of detection in chromatography. *Chromatographia.* 1984; 18 (9) 503-511.
- [22] International Organization for Standardization. Capability of detection. Part 1: Terms and definitions. ISO-11843-1. Geneve: ISO; 1997
- [23] Corley J. Best practices in establishing detection and quantification limits for pesticide residues in foods, in Lee P. (ed.) *Handbook of residue analytical methods for agrochemicals*, West Sussex. John Wiley and sons; 2003. p59-75.
- [24] Armbruster DA, Tillman MD, Hubbs LA. Limit of detection (LOD)/limit of quantification (LOQ): comparison of the empirical and the statistical methods exemplified with GC-MS assays of abused drugs. *Clin. Chem.* 1994; 40(7) 1233-1238.
- [25] Long GL, Winefordner JD. Limit of detection, a closer look at the IUPAC definition. *Anal.Chem.* 1983; 55(7), 712A-724A.
- [26] Currie LA. Limits for qualitative detection and quantitative determination. *Anal.Chem.* 1968; 40(3) 586-593.
- [27] Chang KH. Limit of detection and its establishment in analytical chemistry. *Health Env. J.* 2011; 2(1) 38-43.
- [28] Lavagnini I, Magno F. A statistical overview on univariate calibration, inverse regression and detection limits. Application to GC/MS technique. *Mass Spect. Rev.* 2007; 26, 1-18.

- [29] API, Analytical detection and quantification limits: survey of state and federal approaches. Pub. No. 4721, Washington: American Petroleum Institute; 2002
- [30] Currie LA. Detection and quantification limits: origins and historical overview. *Anal. Chim. Acta* 1999; 391(2) 127-134.
- [31] Currie LA. Detection: international update, and some emerging di-lemmas involving calibration, the blank and multiple detection decisions. *Chem. Intell. Lab. Sys.* 1997; 37, 151-181.
- [32] Hubaux, A. Vos, G. Decision and detection limits for linear calibrations curves. *Anal. Chem.* 1970; 42(8) 849-855.
- [33] Needleman SB, Romberg RW. Limits of linearity and detection for some drugs of abuse. *J. Anal. Tox.* 1990, 14(1) 34-38.